BODET Scorepad





User manual - Volleyball

For software version V1.1B01



www.bodet-sport.com

BODET SA

BP30001 49340 Trémentines I FRANCE Tel: +33 (0)2 41 71 72 98 Fax: +33 (0)2 41 71 72 01







1. Volleyball

- 1) Select 🦃 .
- 2) Select a configuration from the list:

Configurations identified by \bigcirc can only be edited with the club access code. The club Access code is "1234". It can be changed in the "Club access" menu.

3) Screen in 5-set VOLLEYBALL match mode:



Pressing a game setting brings up a new window used to:

- assign the serve to a player.
- 2 call a time-out. To start the countdown, press the START > button. Add or delete a time-out by pressing Correct >.
- edit the name of the team. After pressing LOCALS or VISITORS, press Config. team to edit the configuration of the teams (edit team screen name, activate players, choice of colours, load a team, create a new team or delete a team):



- 4 display sets. Press once to correct the results of sets or to delete the last set.
- 5 add a point to the team.
- 6 edit the configuration settings (see next page for the list of settings).
- designate the set winning team (Home or Guest).

- 8 designate the match winning team (home or guest). possibility to select: withdrawal or else.
- 1 start a new match. Caution: the match in progress will be lost.

> ENTERING CONFIGURATION SETTINGS

1) Click 🔑 to edit a configuration.

Note: All these settings are accessible from the Advanced Settings menu.

The list of editable settings is given below:

Headings	Settings	Default values	Description	Standard settings
Match				
	Number of sets won	3	Function enabled using the ON/OFF button 1 to 3 sets in steps of 1	✓
	Number of points per set	25	1 to 60 points in steps of 1	✓
	Final set number of points	15	1 to 60 points in steps of 1	V
	Points difference Rally point	2 ON	1 to 9 points in steps of 1 Function enabled using the ON/OFF button	√ √
Display	7.		,	•
	Set duration Match duration	ON ON	Function enabled using the ON/OFF button Function enabled using the ON/OFF button	-
Time-out				
	Manual number of time-outs	1	1 or 2 time-outs	-
	Technical time-out duration	60s TM T1 :8 TM T2 :16	Duration of time-out from 0 to 5 minutes and 0 to 59 secondes in steps of 1 Activation of 1 and 2 technical time-outs with ON/OFF button 1 to 60 points in steps of 1	-
	Manual time-out duration	0:30	Function enabled using the ON/OFF button 0 to 5 minutes in steps of 1 0 to 59 seconds in steps of 1	-
	Time-out buzzer	10s ON	Function enabled using the ON/OFF button 1 to 20 seconds in steps of 1	-
Miscellaneo	us			
	Maintain result	20s	1 to 99 seconds in steps of 1	-
HDMI				
	Load image	ON	Enabling wallpaper image (if OFF = wallpaper black)	-
Function key	/s			
	Set won	ON	Function enabled using the ON/OFF button	-
	Match won	ON	Function enabled using the ON/OFF button	-
	Alpha message	OFF	Function enabled using the ON/OFF button	-